






Types of Field Effect Transistors






Junction Field Effect Transistor (JFET)




JFETs are three-terminal voltage-controlled semiconductor devices that can be used to control switches or amplifiers.

There are two JFET types:

- n-channel and p-channel.
- Similar in physical structure to a BJT.
 - It is also a 3-terminal device
 - There are two pn-junctions






• However, JFET is a Voltage Controlled Device, as opposed to a Current Controlled Device in the case of the BJT.



Junction Field Effect Transistor (JFET)






- (a) The basic structure of the junction field effect transistor (JFET) with an n-channel. The two p^+ regions are electrically connected and form the gate.
 - (b) A simplified sketch of the cross section of a more practical *n*-channel JFET









- (a) The gate and source are shorted ($V_{GS} = 0$) and V_{DS} is small,
- (b) V_{DS} has increased to a value that allows the two depletion layers to just touch. This is called pinch-off voltage, $V_{DS} = V_P (= 5 \text{ V})$. Since gate to source is short, $V_{GS} = 0$, $V_{GD} = -V_{DS} = -V_P = -5 \text{ V}$. (c) V_{DS} is large $(V_{DS} > V_P)$ so that a short length of the channel is pinched off.











Pinched off


channel

(b) V_{DS} has increased to a value that allows the two depletion layers to just touch, when $V_{DS} = V_P (= 5 \text{ V})$ when the $p^+ n$ junction voltage at the drain end, $V_{GD} = -V_{DS} = -V_P = -5 \text{ V}$. (c) V_{DS} is large $(V_{DS} > V_P)$ so that a short length of the channel is pinched off.

 $V_{DS} = 10 \text{ V}$








(b) V_{DS} has increased to a value that allows the two depletion layers to just touch, when $V_{DS} = V_P (= 5 \text{ V})$ when the $p^+ n$ junction voltage at the drain end, $V_{GD} = -V_{DS} = -V_P = -5 \text{ V}$. (c) V_{DS} is large $(V_{DS} > V_P)$ so that a short length of the channel is pinched off.

JFET Principles: Channel Pinch-off






Pinch-off Condition with $V_{Gs} = 0$

$$V_{GD}(\text{pinch-off}) = -V_P$$

 V_{DS} has increased to a value that allows the two depletion layers to just touch, when $V_{DS} = V_P (= 5 \text{ V})$ when the $p^+ n$ junction voltage at the drain end, $V_{GD} = -V_{DS} = -V_P = -5 \text{ V}$.


University JFET Principles: Beyond Channel Pinch-off of Glasgow





Electrons in the n-channel drift toward P. When they arrive at P, they are swept across the pinched-off channel by E-field. This process is similar to minority carriers in the base of a BJT.






Drain current, I_D , is actually determined by the <u>resistance of the conducting n-channel</u> over L_{ch} from A to P.

Thus
$$I_D = \frac{V_P}{R_{AP}}$$
 $(V_{DS} > V_P)$

University JFET Principles: Beyond Channel Pinch-off of Glasgow





As V_{DS} increases, most of the additional voltage simply drops across l_{po} as this region is depleted of carriers and hence highly resistive.



University Junction Field Effect Transistor (JFET)



- We first considered the behavior of the JFET with the gate and source shorted ($V_{GS} = 0$). The resistance between S and D is the resistance of the conducting n-channel between A and B, R_{AB} .
- When a positive voltage is applied to D with respect to S ($V_{DS} > 0$), then a current flows from D to S which is called the drain current I_D.
- There is a voltage drop along the channel, between A and B. The voltage in the n-channel is zero at A and V_{DS} at B.
- As the voltage along the n-channel is positive, the pn junctions between the gates and the n-channel become progressively more reverse-biased from A to B. Consequently, the depletion layers extend more into the channel and thereby decrease the thickness of the conducting channel from A to B.
- Increasing V_{DS} increases the widths of the depletion layers, which penetrate more into the channel and hence result in more channel narrowing toward the drain.
- The resistance of the n-channel R_{AB} therefore increases with V_{DS} . The drain current therefore does not increase linearly with V_{DS} .




JFET Principles: Effect of V_{GS}




Note the thicker depletion region

$$V_{DS(sat)} = V_{GS} + V_p$$

Thus, a smaller V_{DS} is needed to pinch off channel (say $V_{DS}=3V$)






(a) The JFET with a negative V_{GS} bias has a narrower n-channel at the start. (b) Compared to the $V_{GS} = 0$ case, the same V_{DS} gives less I_D as the channel is narrower. (c) A smaller voltage is required for pinch-off. The channel is pinched off at $V_{DS} = 3$ V sooner than the $V_{GS} = 0$ case where it was $V_{DS} = 5$ V.



JFET Characteristics






Typical I_D vs. V_{DS} characteristics of a JFET for various fixed gate voltages V_{GS} .



University of Glasgow JFET Principles: Beyond Channel Pinch-off









Junction Field Effect Transistor (JFET)

Pinch-off condition

$$V_{DS(\text{sat})} = V_P + V_{GS}$$

$$V_{DS(\text{sat})} = V_P + V_{GS}$$
 $I_D \approx I_{DS} \approx \frac{V_{DS(\text{sat})}}{R_{AP}(V_{GS})} = \frac{V_P + V_{GS}}{R_{AP}(V_{GS})}$

where V_{GS} is a negative voltage (reducing $V_{DS (sat)}$) and R_{AP} is the effective resistance of the n-channel from A to P.

Beyond pinch-off when $V_{DS} > V_{DS(sat)}$, the point P where the channel is just pinched still remains at potential V_P , thus V_{AP} remains at $V_{DS(sat)}$, given by the above equation.





Junction Field Effect Transistor (JFET)


- The resistance increases with more negative gate voltage as this increases the reverse bias across the p⁺n junction, which leads to the narrowing of the channel.
 - e.g. when $V_{GS} = -4$ V, the channel thickness at A becomes narrower than in the case with $V_{GS} = -2$ V, thereby increasing the resistance (R_{AP}) of the conducting channel and therefore decreasing I_{DS} .
- Further, there is a reduction in the drain current by virtue of $V_{DS(\text{sat})}$ decreasing with negative V_{GS} .
- These two effects (i.e. from $V_{DS(\text{sat})}$ and that from R_{AP}) lead to I_{DS} almost decreasing parabolically with $-V_{GS}$.



JFET with Turn-off V_{GS}



When the gate voltage is such that $V_{GS} = -V_p$ (= -5 V) with the source and drain shorted ($V_{DS} = 0$), then the two depletion layers touch over the entire channel length and the whole channel is closed. The channel is said to be off. The only drain current that flows when a V_{DS} is applied is due to the thermally generated carriers in the depletion layers. This current is very small.




When $V_{GS} = -5$ V the depletion layers close the whole channel from the start, at $V_{DS} = 0$. As V_{DS} is increased there is a very small drain current which is the small reverse leakage current due to thermal generation of carriers in the depletion layers.



JFET Transfer Characteristics





(a) Typical I_{DS} versus V_{GS} characteristics of a JFET. (b) The dc circuit where V_{GS} in the gate—source circuit (input) controls the drain current I_{DS} in the drain—source (output) circuit in which V_{DS} is kept constant and large ($V_{DS} > V_P$).





Junction Field Effect Transistor (JFET)

Beyond pinch-off

A simple way to express the relationship between I_{DS} and V_{GS} is:

$$I_{DS} = I_{DSS} \left[1 - \left(\frac{V_{GS}}{V_{GS(\text{off})}} \right) \right]^{2}$$

where,

 I_{DSS} is the drain current when $V_{GS} = 0$

 $V_{GS(\text{off})} = -V_p$; the gate-source voltage that just pinches off the channel





JFET SUMMARY

Two important facts about the JFET:

- Modulating the electric field in the reverse-biased depletion layers (by changing V_{GS}) varies the depletion layer penetration into the channel and hence the resistance of the channel. The transistor action hence can be thought of as being based on a field effect. Since there is a pn junction between the gate and the channel, the name has become <u>JFET</u>. This junction in reverse bias provides the isolation between the gate and channel.
- Secondly, the region beyond pinch-off is commonly called the current saturation region, as well as constant current region and pentode region. The term saturation should not be confused with similar terms used for saturation effects in bipolar transistors. A saturated BJT cannot be used as an amplifier, but *JFETs are invariably used as amplifiers in the saturated current region*.






JFET Commons Source Amplifier

- The transistor action in the JFET is the control of I_{DS} by V_{GS} . The input circuit is the gate-source circuit containing V_{GS} and the output circuit is the drain-source circuit in which the drain current I_{DS} flows.
- The JFET is almost never used with the pn junction between the gate and channel forward-biased ($V_{GS} > 0$).
- With V_{GS} limited to negative voltages, the maximum current in the output circuit can only be I_{DSS} . The maximum input voltage V_{GS} should therefore give an I_{DS} less than I_{DSS} .





JFET Commons Source Amplifier




- (a) Common source (CS) ac amplifier using a JFET. Both input and output circuits are connected to the same source.
- (b) Explanation of how I_D is modulated by the signal v_{gs} in series with the dc bias voltage V_{GG} , supposing that v_{gs} varies sinusoidally between -0.5 V and +0.5 V.










v_{gs}	V_{GS}	I_{DS}	$i_d = \delta I_{DS}$		v_{ds}	Voltage		
(V)	(V)	(mA)	(mA)	$V_{DS} = V_{DD} - I_{DS}R_D$	(V)	Gain	Comment	
0	-1.5	4.9	0	8.2	0		dc conditions, point Q	
-0.5	-2.0	3.6	-1.3	10.8	+2.6	-5.2	Point A	
+0.5	-1.0	6.4	+1.5	5.2	-3.0	-6	Point B	

NOTE: $V_{DD} =$ 18 V and $R_D =$ 2000 Ω .







v _{gs} (V)	V _{GS} (V)	I _{DS} (mA)	<i>i_d</i> (mA)	$V_{DS} = V_{DD} - I_{DS}R_D$	v _{ds} (V)	Voltage Gain	Comment
0	-1.5	4.9	0	8.2	0		dc conditions, point Q
-0.5	-2.0	3.6	-1.3	10.8	+2.6	-5.2	Point A Asymetric
-0.5 + 0.5	-1.0	6.4	+1.5	5.2	-3.0	-6	Point B " I_{DS} —


NOTE: V_{DD} = 18 V and R_D = 2000 Ω .

$$I_{DS} = I_{DSS} \left[1 - \left(\frac{V_{GS}}{V_{GS(\text{off})}} \right) \right]^2$$

relationship







(V)	V _{GS} (V)	I _{DS} (mA)	i _d (mA)	$V_{DS} = V_{DD} - I_{DS}R_D$	(V)	Voltage Gain	Comment	
0	-1.5	4.9	0	8.2	0		de condition	ns, point Q
-0.5	-2.0	3.6	(-1.3)	10.8	+2.6	-5.2	Point A	Asymetr
+0.5	-1.0	6.4	+1.5	5.2	-3.0	-6	Point B	
								$"I_{DS}$ -

NOTE: V_{DD} = 18 V and R_D = 2000 Ω .


$$v_{ds} = -R_D i_d$$

Asymetric due to $"I_{DS} - V_{GS}"$ relationship

$$I_{DS} = I_{DSS} \left[1 - \left(\frac{V_{GS}}{V_{GS(\text{off})}} \right) \right]^2$$







Thus the output, v_{ds} , changes from -3.0 V to 2.6 V. The peak-to-peak voltage amplification is

$$A_{V(pk-pk)} = \frac{\Delta V_{DS}}{\Delta V_{GS}} = \frac{v_{ds(pk-pk)}}{v_{gs(pk-pk)}} = \frac{-3 \text{ V} - (2.6 \text{ V})}{0.5 \text{ V} - (-0.5 \text{ V})} = -5.6$$

The negative sign represents the fact that the output and input voltages are out of phase by 180°





JFET Amplifier

- The amplification can be increased by increasing R_D , but we must maintain V_{DS} at all times above $V_{DS(sat)}$ (i.e. beyond pinch-off) to ensure that the drain current I_{DS} in the output circuit is only controlled by V_{GS} in the input circuit.
- When the signals are small about dc values, we can use differentials to represent small signals. For example, $v_{gs} = \delta V_{GS}$, $i_d = \delta I_{DS}$, $v_{ds} = \delta V_{DS}$ and so on. The variation δI_{DS} due to δV_{GS} about the dc value may be used to define a mutual transconductance g_m for the JFET.

University of Glasgow JFET Common Source Amplifier

Definition of the JFET transconductance (small signal)

$$g_{m} = \frac{dI_{DS}}{dV_{GS}} \approx \frac{\delta I_{DS}}{\delta V_{GS}} = \frac{i_{d}}{v_{gs}}$$

JFET transconductance (small signal)

$$g_{m} = \frac{dI_{DS}}{dV_{GS}} = -\frac{2I_{DSS}}{V_{GS(\text{off})}} \left[1 - \left(\frac{V_{GS}}{V_{GS(\text{off})}} \right) \right] = \frac{-2[I_{DSS}I_{DS}]^{1/2}}{V_{GS(\text{off})}}$$





Glasgow JFET Common Source Amplifier

Small-signal voltage gain

$$A_V = \frac{v_{ds}}{v_{gs}} = \frac{-R_D i_d}{v_{gs}}$$

$$\therefore A_V = \frac{-R_D(g_m v_{gs})}{v_{gs}} = -g_m R_D$$

$$\therefore A_V = -\mathbf{g}_m R_D$$

The negative sign indicates that the output and input voltages are out of phase by 180°

JFET – Example 1




THE JFET AMPLIFIER Consider the *n*-channel JFET common source amplifier shown in Figure 6.34a. The JFET has an I_{DSS} of 10 mA and a pinch-off voltage V_P of 5 V as in Figure 6.34b. Suppose that the gate dc bias voltage supply $V_{GG} = -1.5$ V, the drain circuit supply $V_{DD} = 18$ V, and $R_D = 2000 \Omega$. What is the voltage amplification for small signals? How does this compare with the peak-to-peak amplification of -5.6 found for an input signal that had a peak-to-peak value of 1 V?

We have already solved this problem; however, the previous solution can be simplified by using the below equations

$$A_V = -\boldsymbol{g}_m R_D$$

$$g_{m} = \frac{dI_{DS}}{dV_{GS}} = -\frac{2I_{DSS}}{V_{GS(\text{off})}} \left[1 - \left(\frac{V_{GS}}{V_{GS(\text{off})}} \right) \right] = \frac{-2[I_{DSS}I_{DS}]^{1/2}}{V_{GS(\text{off})}}$$






JFET – Example 2



The JFET amplifier Consider an n-channel JFET that has a pinch-off voltage (V_P) of 5 V and $I_{DSS} = 10$ mA. It is used in a common source configuration as shown, in which the gate to source bias voltage (V_{GS}) is -1.5 V. Suppose that $V_{DD} = 25$ V.

- a. If a small signal voltage gain of -10 is needed, what should be the drain resistance (R_D) ? What is V_{DS} ?
- b. If an ac signal of 1 V peak-to-peak is applied to the gate in series with the dc bias voltage, what will be the ac output voltage peak-to peak? What is the voltage gain for positive and negative input signals? What is your conclusion?







Task - BJTs and FETs Differences

• What are the main differences between BJTs and FETs? Think in terms of device control, power consumption, applications, etc.